#### §401.60

#### RADIO COMMUNICATIONS

# § 401.60 Listening watch and notice of arrival.

(a) Vessels shall be on radio listening watch on the applicable assigned frequency while within a Seaway traffic control sector as shown on the General Seaway Plan and shall give notice of arrival in the manner prescribed in § 401.64 upon reaching any designated calling in point.

(b) Notice of arrival shall be deemed to have been given when it is acknowledged by a Seaway station.

#### § 401.61 Assigned frequencies.

The Seaway stations operate on the following assigned VHF frequencies:

156.8 MHz—(channel 16)—Distress and Calling.

156.7 MHz—(channel 14)—Working (Canadian Stations in Sector 1 and the Welland Canal).

156.6 MHz—(channel 12)—Working (U.S. Station in Lake Ontario)

156.6 MHz—(channel 12)—Working (U.S. Stations in Sector 2 of the River). 156.55 MHz—(channel 11)—Working (Canadian Stations in Sector 3, Lake Ontario and Lake Erie).

[75 FR 10689, Mar. 9, 2010]

#### § 401.62 Seaway stations.

The Seaway stations are located as follows:

VDX20 (Seaway Beauharnois)—Upper Beauharnois Lock—Traffic Control Sector No. 1.

KEF (Seaway Eisenhower)—Eisenhower Lock—Traffic Control Sector No. 2.

VDX21 (Seaway Iroquois)—Iroquois Lock— Traffic Control Sector No. 3.

WAG (Seaway Clayton)—Clayton, N.Y.— Traffic Control Sector No. 4.

WAG (Seaway Sodus)—Sodus, N.Y.—Traffic Control Sector No. 4.

VDX72 (Seaway Newcastle)—Port Hope, Ontario-Traffic Control Sector No. 5.

VDX70 (Seaway Newcastle)—Port Weller, Ontario-Traffic Control Sector No. 5.

VDX22 (Seaway Welland)—St. Catharines, Ontario—Traffic Control Sector No. 6.

VDX68 (Seaway Long Point)—Port Colborne, Ontario—Traffic Control Sector No. 7.

(68 Stat. 93–96, 33 U.S.C. 981–990, as amended and secs. 4, 5, 6, 7, 8, 12 and 13 of sec. 2 of Pub. L. 95–474, 92 Stat. 1471)

[39 FR 10900, Mar. 22, 1974, as amended at 40 FR 25813, June 19, 1975; 45 FR 52379, Aug. 7, 1980]

## § 401.63 Radio procedures.

Every vessel shall use the channels of communication in each control sector as listed in the table to this section.

### CHANNELS OF COMMUNICATION

Station	Control sector number	Sector limits	Call in	Work	Listening watch
Seaway Beauharnois Seaway Eisenhower Seaway Iroquois Seaway Clayton Seaway Sodus Seaway Newcastle Seaway Welland Seaway Ung Point	2 3 4 4 5 6	C.I.P No. 2 to C.I.P No. 6–7 C.I.P. No. 6–7 to C.I.P. No. 10–11 C.I.P. No. 10–11 To Crossover Island Crossover Island to Cape Vincent Cape Vincent to Mid Lake Ontario Mid Lake Ontario To C.I.P. No. 15 C.I.P. No. 15 to C.I.P. No. 16	Ch. 12 Ch. 11 Ch. 13 Ch. 12 Ch. 11 Ch. 14	Ch. 12 Ch. 11 Ch. 13 Ch. 12 Ch. 11 Ch. 14	Ch. 12. Ch. 11. Ch. 13. Ch. 16. Ch. 16. Ch. 14.

[75 FR 10690, Mar. 9, 2010]

## §401.64 Calling in.

(a) Every vessel, intending to transit or in transit, shall report on the assigned frequency to the designated Seaway station when opposite any calling in point or checkpoint (indicated on the General Seaway Plan) and, when reporting, shall give the information indicated in Schedule III.